




## Assembling the door

Page 10 of the assembly instructions details how to mount the door onto the greenhouse.

Whilst the assembly instructions advise you to mount the door to the front before you attach it to the gables, we recommend that you mount the door at the end.




Pull slightly on part no. 86 and push the head of the door roller no.



In the bottom of the door, slide the "legs" of the door roller no.

62 into the gutter no. 32.



The top of the door can be adjusted using the long slit in the door roller no. 62.


We recommend greasing the door to make it slide more easily.

into the base sill no. 30.



The bottom of the door can also be adjusted using the long slit in the door roller no. 62.

Please ensure that the "legs" in the door roller fix the door tightly against the greenhouse frame so that it cannot be blown away.



Screw part no. 82 into doorstop no. 69.



Now push the doorstop no. 69 into the gutter whilst holding the door steady.

The door is now mounted.